


## Loading shares data from USB

Receiver software enable to load all sharing settings directly from simple text file. Text file name must be set to: **allshares.dat** and look like:



```
1 C: url11.cccam.com 38000 login password
2 C: url11.cccam.com 39000 login password
3 N: url11.newcamd.com 38000 38005 login password 0102030405060708091011121314
4 N: url12.newcamd.com 39000 39005 login password 0102030405060708091011121314
5
```

To update all sharing settings from file go to → *Upgrade By USB* and choose:

